

Please read these instructions carefully before starting to use the product.

Opening and closing the cabinet

To open the cabinet:

1. Unlock the lock(s)
2. Turn the handle clockwise

To close the cabinet:

1. Make sure that the bolts are not extended
2. Push the door against the cabinet without moving the handle until the handle turns slightly anticlockwise
3. Turn the handle to its final position
4. Lock the lock(s)

Locks

Refer to the separate lock instructions for information about the lock itself.

The locks are located behind a panel on the inside of the door. If there is a need to access the locks, follow the instructions below:

1. Open the door and extend the bolts by pushing on the blocking device, see below



2. Unscrew the screws and open the inner door to reach the lock area



After completion:

1. Close the inner door and attach it with the screws
2. Turn the handle clockwise until the bolts are retracted and blocked in the door before closing the door

Interior fittings

Extensible shelves

Mount the slides to the walls by entering it from a horizontal position and then turn it down to a vertical position. Between every fifth slit in the racking strips on the wall there is a mark to make it easier to find the correct slit.



Pull out the slides on both sides and press the shelf onto the hooks on the slides.



Mount the dividers into the drawer.

Compartment

Mount the clips in the racking strips on the wall. Between every fifth slit in the racking strips on the wall there is a mark to make it easier to find the correct slit.

Place the compartment on the clips.



Fix the compartment to the cabinet with the enclosed four screws. Don't tighten the screws to hard; it may deform the wall of the compartment. Adjust the screws to get an even slit around the door which guarantees a smooth operating compartment door and lock.



Maintenance

Cleaning

Use a soft cloth and a light detergent when cleaning the cabinet. Ensure that all moisture is removed before closing the cabinet.

Do not use any chemical solvents.

Airing the cabinet

The storage compartment is protected by a high performance seal to prevent moisture to enter during a fire. We recommend that the cabinet is opened at least once a month to avoid humidity problems.

If you are in need of service

Always turn to an authorized service organization.

A serial number is to be found on a plate fixed on the left hand side of the base. The serial number, in combination with your invoice, will help the after sales service to identify the product and secure an efficient service.